

JD Air Parts V2 Fuel Drain Fairings.

This new design is smaller and also features a new and improved mounting system. The new mounting does not require removal of fuel drains or draining fuel from the aircraft. The fairings and clamping shoes are CNC machined from aluminium and clear anodized.

Easy & Quick - Installation Instructions:

1. Partially thread set screw into the fairing.
2. Insert clamping shoe into pocket, the set screw will help hold the shoe in place.
3. Slide Fairing & Shoe onto flange.
4. Gently tighten set screw and adjust the fairings position.
5. Tighten set screw enough to fully secure it to the flange.

